

THE PENNSYLVANIA RAILROAD

LOCOMOTIVE MAINTENANCE INSTRUCTIONS NO. L-58

Issued Philadelphia, Pa.
1946

INSTRUCTIONS FOR OPERATING AND MAINTAINING WORTHINGTON LOCOMOTIVE BOILER FEED PUMP AND FEED WATER HEATER, TYPES SA AND SAS, SIZE 6½

GENERAL

A typical arrangement of the Worthington Type "SA" and "SAS" Locomotive Feedwater Heating Equipment on a locomotive is shown in Fig. 1, page 12.

The cold water pump, "A", takes water from the tender and delivers it to the heater, "B", which is set into the top of the smoke box. Here the water is heated by mixing with the exhaust steam from the locomotive cylinders and hot water pump. From the heater, the hot water flows down to the hot water pump, "C". The hot water pump forces the heated water into the boiler through the boiler check.

COLD WATER PUMP

The cold water pump, "A", consists of a Pyle-National Steam Turbine and a Worthington Centrifugal Pump combined in one casing. The steam which runs this pump is controlled by the float operated valve on the cover of the feed-water heater. The pump will deliver as much or as little water to the heater as is permitted by the opening of this steam valve on the heater cover which is governed by the float.

Fig. 2, page 13, shows a section through the "SA" cold water pump, the turbine being equipped with a single steam nozzle head.

The "SAS" equipment operates the same as the "SA" equipment; however, it is a higher capacity system in that the cold pump turbine, Fig. 3, page 14, is fitted with a two-nozzle head, the steam supply to the second nozzle being controlled by a piston valve, a bellows, and the cold pump discharge pressure. The second nozzle goes into operation when the cold pump water discharge pressure reaches a point between 12 lbs. and 20 lbs.

The steam control valve body (Fig. 4, Ref. 47) on the "SAS" heater has a larger port area than the "SA" body and 1" instead of ¾" connections. The steam line used to supply the steam to the cold pump turbine is increased from a ¾" to a 1" line. These changes and the modification of the turbine to include the two nozzles are the only changes in the Feed Water Heating Equipment of the "SA" type which results in the type designated of "SAS".

The nozzles in the "SAS" cold pump are not interchangeable with those in the "SA" equipment.

HEATER

The cold water is delivered by pump, "A", to the heater, "B", through a spring loaded spray valve (Fig. 4, page 15, part ref. 28). The amount of water passing through the spray valve depends upon the level of the water in the heater. When the water level in the heater is low and the float is down,

the steam control valve which supplies steam to the cold water pump is open and the cold water pump delivers water to the heater. As the water level rises, the float rises, gradually closing the steam control valve, causing the cold water pump to deliver less water to the heater. If the water level is then lowered, the float descends and opens the steam control valve again. The water level in the heater determines the position of the float, the opening of the steam control valve and finally the amount of cold water entering the heater.

Exhaust steam from the locomotive, entering the heater through pipe (part 26, Fig. 1), passes upward through the exhaust check valves (Fig. 4, part ref. 4). Exhaust steam from hot water pump also enters the heater.

Air vent pipes (20, 20A and 24, Fig. 1), permit the escape of the air which separates from the water as it is heated. The open end of pipe "20A" should be in a convenient position near the track where it will be visible for inspection.

HOT WATER PUMP

The hot water pump, "C", is a single horizontal long stroke piston pump, having an enclosed type steam valve gear. The speed of the hot water pump, and the amount of water it takes from the heater and delivers to the boiler, is controlled by the operating valve, (part 33, Fig. 1), conveniently located in the cab. This operating valve is opened just enough to supply the boiler with the amount of water desired.

This hot water pump and its discharge pipe to the boiler are the only parts of the Worthington equipment which are subjected to boiler pressure.

DRIFTING CONTROL VALVE

The drifting control valve, "F", Fig. 1, is placed on the steam inlet to the hot water pump. It is a device which prevents the pump from being run fast while the engine is standing or drifting, and therefore supplying little or no exhaust steam to the heater to heat the feed water. This valve limits the amount of only partly heated water that can be delivered to the boiler should the pump be operated when the locomotive is standing or drifting. This valve is controlled by live steam pressure from one of the locomotive cylinder steam pipes led to the valve by a 3/8" pipe.

The drifting control valve, Fig. 6, page 17, is adjusted at the factory to open when the locomotive steam pipe pressure reaches 50 pounds and to close when the pressure is reduced to slightly below 50 pounds. It requires no attention as the spring is so adjusted that the valve opens when the steam pipe pressure is slightly above locomotive drifting throttle pressure. When the drifting control valve is open, the hot water pump can be run at full speed. When it is closed the hot water pump runs about one-half speed.

In some cases drifting control valves are decommissioned and are open all the time, in which case pump can be operated at full capacity at any time without the action of automatic control. If the pump is fitted with the standard drifting control valve it will run at about one-half speed with locomotive throttle closed, as the drifting control valve automatically closes, but permits sufficient steam to pass through the valve to keep pump operating at this reduced speed on account of a small by-pass port and a loose fitting valve in the drifting control valve assembly. When locomotive throttle is open, as before stated, the drifting control valve is open and pump can be run at full speed. If the pump is equipped with the decommissioned drifting control valve, it will run up to full speed any time that the operating valve in cab is opened.

CAB GAUGE

The cab gauge, "J", Fig. 1, is connected to the cold water pump discharge pipe, and registers the pressure developed by the cold pump, in delivering water to the heater.

STEAM STRAINER

Steam strainers are furnished with each equipment. One with coarse screen, "M", Fig. 1, is located in the steam pipe to the cold water pump, and another, "N", Fig. 1, with fine screen, is located in the steam pipe to the steam control valve in the heater cover.

OPERATION

The height of water in the boiler is regulated by the operating valve, (part 33, Fig. 1), which controls the speed of the hot water pump and the amount of water it delivers to the boiler.

In preparation for starting pumps, all valves, such as tank valve, boiler check, steam turret valve, etc., should be in proper working position. Open cold pump air vent (part 38, Fig. 1), in cab for one-half minute or so to prime pump with water. It is well to run the pump slowly for a few minutes some time before starting out to free the steam pipes and steam cylinder of the hot water pump of condensation in order that the pump may start promptly when required.

In order to get pumps started promptly, open operating valve (part 33, Fig. 1), one-half turn, and as soon as cab gauge indicates pressure, regulate the operating valve so that it feeds water to the boiler at the desired rate. When starting up the equipment, some seconds will elapse between the opening of the operating valve and the indication of pressure on the cold pump gauge. This is because the hot pump must start first, and take some water from the heater, lowering the heater water level, causing the float to open steam control valve and start the cold pump.

The equipment should be run continuously while the locomotive is using steam, and the hot water pump should be operated continuously at the speed necessary to maintain the desired water level in the boiler.

When the locomotive is running light it may be necessary to start and stop the hot water pump instead of operating it continuously. However, an endeavor should be made to take advantage of such times as the locomotive throttle may be open to run the pump in order to recover maximum amount of heat from the exhaust steam.

In connection with the operation of the cab gauge. The cab gauge being connected to the cold water discharge pipe, registers the water pressure developed by the cold pump in delivering water to the heater. This pressure is largely determined by the pressure of the exhaust steam in the heater. A change of the pressure indication of the cab gauge does not necessarily indicate a change in the capacity at which the pumps are delivering water to the boiler. If the tender screen is plugged up, or the tank valve not opened, or if the cold pump is filled with air or steam instead of water, the cold pump gauge will show little or no pressure, or at least somewhat less pressure than is usual for the particular locomotive operating condition. If these conditions exist, they should be corrected.

During freezing weather keep the suction heater pipe valve, (part 31, Fig. 1), cracked open at all times, except when pumps are to be started. Previous to starting pumps, open air vent valve, close the suction heater (anti-freeze) valve and when pumps have started and are pumping water, the anti-freeze valve should again be cracked open. This results in the anti-freeze pipe being protected and also in furnishing a small amount of heat to the cold pump at all times.

During long drifting periods of the locomotive in freezing weather, the anti-freeze valve in suction heater pipe should be opened enough to prevent the tender hose and cold water pump from freezing. If after a very long drifting period it is found that the suction hose has been over-heated and pump will not handle water, shut off pumps, close anti-freeze valve for a short period, and open cold water pump air vent valve in gauge line in cab.

This will vent all air and steam, and pump will prime with water, after which pumps can again be started. In the event that something occurs to the system which prevents engineman from using it to pump water, all drain valves on the hot water pump should be opened, making sure that they are not plugged up with dirt.

The anti-freeze valve in suction heater pipe should always be left open if engine is to stand outside unprotected in cold weather. If the weather is severely cold, the pump operating valve should also be cracked open. This last protective measure should be followed in cold weather of any severity, if hot water pump is on front deck of locomotive.

In the case of a locomotive which has its fire dumped, either on the road or at a terminal, and the engine is to remain outside for a period long enough to permit boiler to get cold, the pumping system should be thoroughly drained. All drain valves should be opened and investigated to see that they are not plugged with dirt. If equipment is drained while boiler is hot, extra care must be taken to prevent leaky boiler checks from permitting water to leak from boiler into pump.

With feedwater heating equipment it is not necessary to fill the boiler while locomotive is standing in order to be ready for a start. The smaller steam requirement of the hot water pump as compared with injector makes it possible to start the pump when the locomotive is started, without losing steam pressure. This method of operation yields the best results both from the heater and the locomotive.

If it is necessary to run the pump at a speed which seems excessive for the work it is doing, this indicates worn piston packing, leaky valves, or choked tank valve, tank strainer or suction strainer.

The sound of the exhaust from the locomotive is softer when using the heater. Allowance should be made for this in judging the amount of work the locomotive is doing and in determining the position of the reverse lever.

Because of the heat recovered from the exhaust steam, and because of the improvement in boiler conditions due to the reduced firing rate, the heater saves from 10 to 20 percent of the coal which otherwise would be required while running. Unless more work is to be done by the locomotive because of the heater, less coal should be fired than when using the injector.

MAINTENANCE

General: During shopping periods the feedwater heating equipment should be dismantled and thoroughly cleaned. Parts should be inspected for excessive wear and reconditioned or replaced, if necessary. Generally, this can be determined by comparing the clearance of the parts with the allowable wear tolerances contained in the various cross-sections and diagrams contained herein.

Cold Water Pump (Fig. 2, Page 13)

As the cold water pump is driven by a Pyle-National steam turbine, for information in regard to it and its lubrication see Locomotive Maintenance Instructions No. L-29.

Once a week an inspection of the oil in the turbine should be made and if necessary enough clean oil of medium or heavy consistency of the grade used for Pyle-National generators should be poured into the two oil cups on the side of the turbine to bring the oil level up to the top of the cups while the pump is not running. Make sure there is no water in the oil chamber.

The secondary nozzle control unit as used with the type 6½ SAS cold water pump turbine should be tested during general repairs to the equipment to be sure there is not excessive steam leakage between piston valve and bushing, that bellows is in good order and to be sure spring does not permit valve to open at less than 12 lbs.

Periodically, a test should be made to ascertain the speed of the pump at which the over-speed control brake shoe contacts its housing. This test can be made in either one of the ways described as follows:

Shop Test:

1. This test is strictly for shop use where pump steam supply can be manually controlled.

Remove the pump casing and use a revolution counter on the shaft. If the shoe contacts with the housing at a speed lower than 5300 R.P.M. or higher than 7000 R.P.M., the brake shoe or its housing, or both, should be renewed.

Unless a revolution counter is used, do not make brake shoe test without water in the pump suction chamber..

Locomotive Test:

2. This test should be the method used wherever possible.

Operate the pump with a positive head of water on the suction and with the discharge blanked. The brake shoe should not contact at a discharge pressure of less than 55 lbs., but must contact before the pressure reaches 90 lbs. If necessary, renew parts as directed above. When making the test note the highest pressure at which shoe contacts the housing, and then quickly discontinue the test to avoid unnecessary wear on the shoe.

If the housing diameter (See Fig. 7, page 18), has not increased more than 1/32 inch in diameter, and it is not excessively scored, it will be necessary to renew shoe only.

If a burr has accumulated on the tip of the brake shoe, it should be removed. If the shoe heads have expanded, the wear should be measured by noting increase of openings, Fig. 7, page 18, at the end of slots. If the opening of any one slot has increased 1/16 inch the shoe should be renewed. Examine the shoe for cracks or defects in the neck which joins the head to the body. The shoes are heat treated.

Impeller: If the hub of the impeller is not smooth it should be refinished, See Fig. 8, page 19, for tolerances. If the clearance between the impeller suction inlet and the pump casing is more than 1/16 inch on the diameter, the casing should be fitted with guide rings so that the difference in diameter of the impeller and guide ring will be between .020 and .030 inch. The stuffing box should be packed so that it is not leaking excessively. Four (4) rings of 1/4" packing are used for the stuffing box.

Heater (Fig. 4, Page 15)

The heater shell and air vent passages should be thoroughly cleaned by removing all scale and other loose matter. Heater assembly with float should not be subjected to more than 75 lbs. hydrostatic pressure. If float is removed, 100 lbs. pressure may be used.

Exhaust check valve service: The tolerances as shown in Fig. 9, page 19, should be followed for limits of wear.

Steam Control Valve: This control valve complete with float, as well as the spray chamber, can readily be removed for inspection or adjustment.

The adjustment of the steam control valve can be properly made by following the procedure specified on Fig. 10, page 20, Steam Control Valve Assembly Diagram, which also indicates limits of wear.

Spray Valve: This valve should be re-ground to its seat. Clearance between the bore and the valve stem should be between .010 and .015 inch when new. The parts should be renewed or reconditioned if the clearance exceeds 1/32 inch. The valve lift should be 5/8 inch, spring initial compressed length 2-7/32 inches with initial compression strength of 18 pounds. Clearance between shoulder around bottom of valve stem and body guide should be 1/4 inch.

Should it ever be desired to wash scale from the heater, this can be done readily by removing the heater cover and spray chamber from the heater and removing the clean-out cover (Fig. 5, page 16, part 20) from the hot water pump. The heater can then be washed out through the hot water suction pipe and clean-out cover opening.

Hot Water Pump (Fig. 5, page 16)

When about to start up new equipment or equipment that has just been overhauled, make sure that the steam strainers (Fig. 1, page 12) items "M" and "N", are in place. The strainer screens also should be occasionally removed and cleaned.

If a newly installed hot water pump refuses to operate, the cause is usually lack of lubrication or dirt has found its way into the reversing valve chest from the steam piping of the locomotive. To correct this, examine lubricator feed and pipe connections to assure oil feeding to pump. If after obtaining proper lubrication, pump does not operate, remove reversing valve and open pump operating valve slightly to blow out dirt. Thoroughly clean reversing valve before replacing.

Steam Cylinder: Dimensions and tolerances for steam cylinder are shown in Fig. 11, page 21. If clearance between the steam piston and cylinder exceeds $3/64$ inch, rebore cylinder and fit with over-size piston.

Side clearance of steam cylinder piston rings should be .002 to .004 inch when new and rings should be replaced if the side clearance exceeds .010 inch. Steam cylinder should not be rebored more than $3/16$ inch over-size.

Steam Valve Gear: The valve gear is of the enclosed type and is entirely steam actuated - See Fig. 11, page 21. There is only one moving part which is the reversing valve itself. It is actuated by steam pressure which flows to one end of the reversing valve chest through a port that is opened when the steam piston moves to the end of its stroke. Because of the differential areas of the reversing valve, the pressure forces the valve to the opposite position of its travel, thus reversing the admission and exhaust of steam to and from the steam cylinder.

The clearance between reversing valve and steam bushing should be between .006 and .009 inch. If this clearance exceeds .024 inch, renew bushing or re-grind to provide an over-size valve. The side clearance of valve rings should be between .002 and .004 inch. If side clearance exceeds .008 inch, the rings should be renewed. In renewing steam chest bushings, press into position with a force between 11 and 20 tons.

Pump Cylinder: Remove all scale and foreign substances from the pump cylinder passages. The clearance between the pump piston and cylinder bore when new should be between .025 and .035 inch. If this clearance exceeds $3/32$ inch, or if the liner becomes wore $3/32$ inch on the diameter, the cylinder liner should be rebored and fitted with an over-size piston. Over-size pistons should be in $1/16$ inch step sizes and liners should not be rebored for more than $1/4$ inch over-size.

When replacing a pump cylinder liner, use a press fit requiring a force of from 25 to 35 tons. The liner should be pressed into cylinder until the end is below the extreme cylinder face $4-1/8$ inches with a permissible variation of $1/16$ inch.

Pump Valve Service: Follow the valve lifts and tolerances as shown in Fig. 12, page 22. To adjust the suction valve lift "A" to compensate for wear of the discharge valve stem, build up the discharge valve stem with stainless steel rod. To adjust the discharge valve lift "B", build up the pump valve cap stem with Stellite, or cast iron rod.

When necessary apply over-size suction valve seats in $1/16$ inch step sizes to a maximum of $3/8$ inch over-size. Also apply over-size discharge valve seats, when necessary, in $1/16$ inch and $1/8$ inch over-size. When applying $1/8$

inch over-size discharge valve seats, the pump cylinder valve chest opening will have to be increased from 4-7/8 inches to 4-15.16 inches diameter.

Pump Piston and Rod: In truing up piston rods, they should not be re-finished smaller than 3/32 inch in diameter under original size. When re-finish the rod, do not reduce the length of the taper on the pump end. After rod has been reduced in size, apply a new gland to fit, bored 1/32 inch larger than diameter of rod. Also apply a solid throat ring with an inside diameter 1/64 inch larger than rod. See Fig. 13, page 23 for dimensions of piston rod stuffing boxes and packing.

The distance between faces of steam and pump pistons should not vary more than plus or minus 3/16 inch.

The pump piston is of the so-called solid or snap ring type and packed with two formed packing rings, Fig. 14, page 24. These rings are soaked in boiling water until thoroughly pliable and sprung into place. The rings are furnished 1/8 inch over diameter size, uncut, for cylinder of approximately standard size, and should be cut only as and when used. Cut ring ends square and so that when sprung into place there will be a gap of 3/32 inch between ends.

Remove any packing rings that are broken or have a gap more than 3/8 inch when in position in cylinder bore.

Stuffing boxes of the piston rod on the steam and water ends should be packed with six rings of 3/8 inch packing. This packing cut in sets to fit the different size rods can be obtained from Worthington. The packing for both stuffing boxes is identical. As obtained from Worthington, one complete set or box contains sufficient for both boxes of one hot water pump.

Drifting Control Valve: This valve, shown in Fig. 6, page 17, is bolted directly to the steam inlet of the hot water pump and all the steam which runs the pump must first pass through this valve.

The clearance between piston and its bore should be between .005 and .007 inch. If this clearance exceeds .020 inch, the bore should be refinished to provide for an over-size piston. The side clearance of piston ring should be between .002 and .004 inch and gap clearance between .005 and .010 inch. If side clearance exceeds .008 inch, or if gap exceeds 3/32 inch, ring should be renewed.

See that operating pipe is not restricted where it connects to locomotive cylinder steam pipe.

When drifting control valve feature is decommissioned, the internal parts and the 3/8" operating pipe are removed, and a plug threaded into the small hole in the lower face of the valve.

If for any reason the water valve caps on hot water pumps must be taken off, it is positively necessary that the pump and heater first be drained of water. If heater and hot pump are not drained, the pressure of the water will unseat the pump suction valves when caps are removed and suction valves may drop into pump cylinder. Always lift discharge valves and make sure suction valves and springs are in proper position.

Caution: Open drain valves, and particularly valve shown on the end of the pump, (Fig. 5, page 16), to release pressure and dispose of hot water before loosening pump valve caps.

PROCEDURE FOR LOCATING TROUBLE

1. Make sure tank valve, steam turret valve, and boiler check stop valve are open.
2. Observe cold water pump -
 - (A) If not running, check as follows:
 - Pump shaft should turn freely by hand.
 - Examine steam strainer at entrance to cold pump and at control valve in heater cover.
 - Examine turbine brake shoe.

- (B) If pump is running overspeed and producing a shrill tone, indicating that brake shoe is contacting. Feel pump casing; if hot, the pump casing may be overheated by too much anti-freeze heating steam, or pump may be full of air instead of water. Open the drain cock in the pump discharge pipe or the air vent valve in cab. If pump is noisy and does not show proper water pressure, examine for defective brake shoe or noisy ball bearing which may be worn or broken. Make sure suction strainer is clean.
3. Observe hot water pump -
- (A) If not running:
Remove and examine the reversing valve.
- (B) If racing, and steam is flowing from the air vent with the cold water pump not running, the control valve in the heater cover may be stuck in the lowest or closed position. If the control valve is free and the pump continues to race, it indicates that both the boiler check valve and the pump valves leak enough to allow steam or water from the boiler to overheat the pump cylinder. The pump cylinder can be re-primed by opening water cylinder drain valves. If pump is delivering some water, but an excessive amount of steam is blowing from the air vent, the pump water cylinder packing probably needs replacing. If the pump speed is slow, it may be on account of lack of lubrication, insufficient boiler check valve lift, foreign matter in the steam cylinder, in reversing valve, or in the steam cylinder choke located under the drifting control valve.
4. Check control valve in heater cover -
- (A) See that top of flattened section of the control valve is flush with the top of the bushing, when the valve is forced all the way down. This setting should cause the top of the round section on the valve to be nearly flush with the top of the bushing when the valve is all the way up. The valve travel should be between 19/32 inch and 21/32 inch.
- (B) Check for free movement of valve.
If the valve is all the way down (an indication that the heater is full of water) pull up on the nut with pliers; if the valve stays part or full way up, it indicates that the valve is sticking. Remove and clean the valve with oil. After setting make sure that it is free. To thoroughly test the valve for free movement, lower the water level in the heater so that the valve is located at about half its travel. If, after forcing the valve down slightly, it immediately returns to its exact former position, it shows that the valve is free, and that float is working properly.

WORK REPORTS

Reports should state as clearly as possible what troubles are encountered on the road. If cause is known it should be reported. If not known, the trouble should be carefully described in work report.

A group of possible troubles, the causes and test used to determine cause, as well as procedure necessary to correct the troubles, follows:
Report: Pump will not work.

Test: Test pumps by opening pump operating valve in cab and observing performance.

Cold water pump - If it does not run:

1. Examine for restricted steam supply which may be located in stuck float valve, disconnected float, dirty steam line strainers, or plugged turbine nozzle.

2. Examine pump stuffing box, which may be pulled up too tight and binding shaft. There should be slight water leak from this box and pump shaft should spin freely with the fingers.

3. Examine turbine brake shoe, which may be binding in housing.

4. Turbine exhaust pipe should have no restrictions.

Hot water pump - If it does not run:

1. Check steam supply to pump.
2. Examine steam valve gear for lack of lubrication, worn rings, broken parts, or foreign matter binding reversing valve.
3. Examine cylinders for an obstruction.
4. Boiler check valve must be open.
5. Disconnect steam cylinder exhaust and check sound of exhaust for steam ring blow.

Report: Pumps run but will not pump water.

Test: Test pumps by opening pump operating valve in cab and observing performance. Take particular notice to see that cold pump speed varies somewhat, which indicates proper movement of float valve in heater.

Cold Water Pump:

1. If cold water pump runs at an extremely high speed, and gives off a high vibrating tone, pump is not getting water. Tank valve may be closed, tank strainer may be dirty, tender may be empty, tank hose lining may be loose and plugging inlet to pump, or pump may be air-bound or over-heated with steam from anti-freeze valve.

If pump is air or steam-bound, stop pump. Open cold water pump air vent valve in cab. Air vent valve must be open long enough to let all air or vapor out of pump casing while pump is not running, to permit pump to completely and properly fill with water.

Hot Water Pump:

1. If cold water pump operates satisfactorily and there is plenty of water in heater, and hot water pump runs but does not pump water, examine hot water pump cylinder packing. If this is cause of trouble, there will be an unusually heavy flow of steam from both vents during running test.

Report: Pump will not supply boiler.

Test: Test pumps by opening pump throttle and observing performance. The drifting control valve, if one is used, should be moved to wide open position and hot pump run at full speed.

Hot Water Pump:

1. If pump responds, and promptly increases its speed when drifting control valve is opened and makes rated speed, the drifting control valve can be eliminated as a possible cause.
2. If pump pounds severely during this test it indicates lack of water and trouble will be located in cold pump end of system. (See Cold Water Pump instruction below). Steam control valve in heater cover will be in wide open (top) position and float in bottom position.
3. If pump jumps on one stroke only, it indicates a leaking or blocked open water valve.
4. If pump makes a fast stroke in both directions but pumps very little water, it indicates cylinder packing in poor condition. If this is the cause, there will be an unusually heavy flow of steam from vent pipes. Poor cylinder packing or leaking valves can also be detected by placing ear next to pump casting and listening for the noise of rushing water.
5. If pumps makes only one-half speed, thoroughly examine drifting control valve and its connection to locomotive steam pipe. Also check turret valve, and boiler check stop valve, and boiler check valve lift. Pump operating valves in cab have been found with stems badly worn, causing erratic pump speeds and undependable control of pumps. See if pump is properly lubricated.

Cold Water Pump:

1. Examine tank valve, tank strainer, and discharge pipe check valve. Examine steam supply to cold pump, which may be restricted by partially plugged nozzle, steam strainers or stuck float valve in heater. Examine cold pump stuffing box packing, which may be binding the shaft. Examine brake shoe, which may be binding in housing. If report still persists, examine clearance between impeller hub and strainer box fit.

2. Examine turbine blades and steam nozzle re-entry tube for wear.
3. If water supply to cold pump is restricted, the gage hand will waver and be very unsteady, when pump is operated at high capacity.
Report: Pump loses prime.

If cold pump gets air or vapor-bound with steam, stop pump, open air vent valve and allow pump to become flooded with water before starting. This may occur directly after a tank hose has been disconnected, or suction strainer cleaned.

If this occurs on the road it is possibly because suction anti-freezing valve is feeding too much steam to suction line, or because tank has become dry of water. If tank runs dry and is filled at a water plug, open cold water pump air vent valve in cab. If this trouble persists, report "Air vent valve does not prime pump". It may also be due to a spray valve blocked wide open with stray material.

Report: Water wastes from heater vent pipes.

The cause is a stuck or loose float valve in the heater, which can usually be detected by removing the small cap over this valve on heater cover and either pushing or pulling valve carefully with a pair of pliers. If float is disconnected, steam control valve will be in lower position and will offer no resistance to being lifted with pliers. If valve lock nut has become loosened so valve is turning on stem, adjust valve by screwing valve up or down on the threaded rod.

Report: Pump pounds.

If hot water pump pounds it is usually due to lack of water and the same remedies apply as described under - "Report: Pump will not supply boiler. Cold Water Pump".

Report: Cold water pump gage pressure very high but hot water pump pounds and won't supply boiler.

Under this condition, the cold water pump is primed with water, but is having difficulty in delivering it to the heater. Causes of this trouble are, possibly, sticking cold pump pipe line check valve, sticking spray valve, and plugged vent pipes. Frequently this trouble is not evident unless pumps are tested at full speed, as line check or spray valve may be stuck partially open. Vent pipe separator nipple in heater cover should be examined and the hole in heater cleaned out.

Report: Hot pump will not run at full speed.

(A) Examine drifting control valve.

(B) Examine steam turret, pump operating valves, and steam pipe line for restrictions.

(C) Examine boiler check lift.

Report: Pump fails at times to pick up water if started after locomotive throttle is opened.

Trouble may be due to spray valve stuck open, see above.

If this is the case, pumps should be started before engine throttle is opened.

MONTHLY INSPECTION

The following items of work should be performed at Monthly Inspection:

1. Screens for steam line strainers "M" and "N", Fig. 1, must be removed and cleaned, or replaced if necessary.
2. Examine tank valve to see that passage is entirely clear.
3. Remove and clean cold water pump suction strainer screen.
4. Examine boiler check internally. See that boiler check spring is in good condition and the lift is 7/32".

5. The heater cover should be removed and a careful examination made of the exhaust valves, spray valve and steam control valve with its float.

REPAIRS TO THE PUMPS AND HEATER AT ENGINEHOUSES

Parts to be repaired or renewed at enginehouses must be limited to the following: All other repairs must be made at central repair points.

Cold Water Pump:

1. Ball bearings.
2. Impeller shaft packing (pump end).
3. Packing rings (turbine end).
4. Drain valves.
5. Suction strainer.
6. Tank strainer.
7. Line check valve in discharge pipe.
8. Turbine steam strainer.

9. Examination of turbine wheel for wear of buckets and renewal if necessary.

Heater:

1. Steam control valve adjustment.
2. Exhaust check valves.
3. Renewal of control valve float springs, providing the proper size and material of rivets is used.
4. Renewal of the various gaskets used in connection with the cover, providing standard gaskets are used.
5. Control valve steam strainer.

Hot Water Pump:

1. Renewal of reversing valve (Repairs to be made at Back Shops).
2. Hot water pump piston packing.
3. Piston rod packing, steam and water ends.
4. Suction and discharge valve and springs.
5. Drain valves.

H. T. COVER,
Chief of Motive Power.




FIG. 1. Typical Installation of the Worthington Types SA and SAS Locomotive Feedwater Heating Equipment.

Cold water pump "A", takes water from the tender and delivers it to heater "B" where it is heated by mixing with the exhaust steam from locomotive cylinders and not water pump. The heated water then flows down to the hot water pump "G" which forces it into the boiler.

Parts referred to by Letters are furnished by Worthington
Parts referred to by Numbers are furnished by customer

LIST OF PARTS			LIST OF PARTS		
REF.	NAME OF PART	REF.	NAME OF PART	REF.	NAME OF PART
1	Cold water pump	14	Hot water pump discharge pipe	25	Heater saddle
A	Heater	15	Swing check valve	26	Locomotive exhaust pipe to heater
B	Hot water pump	16	Cold water pump suction pipe	27	Turbine steam pipe to control valve
C	Steam turbine	17	Hot water pump suction pipe	28	Connection for mechanical lubrication
D	Control valve	17A	Hot water pump suction pipe (inside smoke box)	29	Connection for hydrostatic lubricator
E	Drifting control valve	18	Drifting control valve actuating pipe	30	Pipe valve (anti-freeze valve)
F	Cold water inlet flange	19	Heater air vent choke	31	Steam turret valve
G	Hot pump exhaust inlet flange	20	Air vent drain pipe in smoke box	32	Operating valve
H	Air vent flange	20A	Air vent drain pipe	33	Cab gauge connection pipe
I	Cab gauge	21	Loco exhaust pump bracket	34	Cab gauge pipe
J	Cab gauge cock	22	Boiler check valve	35	Thermostat well connection
K	Drain valve	23	Heater air vent pipe	36	Suction heater pipe chokes
L	Turbine steam strainer	24	Hot water pump exhaust pipe	37	Valve for air vent and wetting down hose connection
M	Control valve steam strainer			38	Turbine exhaust header
N				39	Turbine exhaust header drain
				40	




FIG. 2. Type SA - Cold Water Pump.

Pump parts to be ordered from Worthington.

Turbine parts to be ordered from Pyle-National Co.


Ref. No.	Part No.	NAME OF PART	Ref. No.	Part No.	NAME OF PART
1	28939	Pump casing	19	PN-COT-11	Cotter pin for turbine wheel nut
	29780	Steam Lines Strainer at Entrance to Turbine (1") SARCO Fitted with Screen #29782 having 3/32 Holes for 64-SA only	20	PN-9101	Turbine casing
	29801	Steam Lines Strainer at Entrance to Turbine (1") SARCO Fitted with Screen #29797 having 3/32 Holes for 64-SAS only	21	PN-9101-G	Gasket for brake shoe housing
2	28959	Impeller	22	PN-9101-P	Turbine brake shoe housing
3	28943	Strainer	23	PN-9186	Oil slinger
4	28942	Stuffing box cap	24	PN-9124	Shaft and key
5	28740	Stuffing box gland	25	PN-9102	Turbine cover
6	29060	Packing for impeller shaft	26	PN-9112-ACP	Turbine wheel
7	28940	Stuffing box	27	PN-9146-A	Brake shoe
8	29384	Drain valve	28	PN-213-SB	Flat head brass machine screw
9	15493	Drain valve nipple	29	PN-3024-K	Key
10	28945	Strainer cover	30	PN-9121	Wheel retaining nut
11	358	Nut for strainer cover	31	PN-9137	Guide passage
12	28843	Stud for strainer cover	32	PN-11	Exhaust screen
13	29030	Packing for strainer cover	33	PN-9116	Outer packing sleeve
14	20706	Socket pipe plug	34	PN-1668-A	Packing ring
15	2318	Cotter pin	35	PN-9115-A	Retainer and packing ring PN-1668-A
16	29300	Locking pawl	36	PN-9104	Ball bearing housing cap
17	29301	Locking pawl pin	37	PN-9104-G	Ball bearing cap gasket
18	29189	Packing for strainer cover	38	PN-9125	Turbine end ball bearing
59	28748	Guide ring 1/2" undersize	39	PN-4006	Eye bolt
60	19209	Screw for guide ring	40	PN-9185	Pump end ball bearing
V2	28714	Gasket for pump stuffing box	41	PN-9162	Ball bearing retaining plate
			42	PN-9178-G	Ball bearing housing gasket
			43	PN-9178	Pump ball bearing housing
			44	PN-9128	Ball bearing nut
			45	PN-209	Oil cup cover chain screw
			46	PN-3519-A	Oil cup cover
			47	PN-1619-A	Oil cup cover chain
			48	PN-3519-B	Oil cup body
			48A	PN-3519-BCP	Oil cup complete
			49	PN-9179-A	Stuffing box cover
			50	PN-9180-C	Hinge pin 7 5/8" long
			51	PN-9135-AC	Nozzle block with dowel pins
			51A	PN-9135	Nozzle block complete with nozzle PN-9137-B
				PN-9135-C	Nozzle block complete with nozzle PN-9137-C
				PN-9135-D	Nozzle block complete with nozzle PN-9137-D
			52	PN-9137-D	Nozzle .236 inch diameter
			53	PN-9131-N	Nozzle lock nut
			54	PN-19-JC	Countersunk pipe plug
			55	PN-559	Dowel pin
			56	PN-1946-E	Dowel pin
			57	PN-LTB-4-A	Thumb nut
			58	PN-9179-B	Thumb nut screw

The steam turbine parts are the same for all size equipments, with the exception of steam nozzle part No. PN-9137-D, the size of which depends upon the locomotive boiler pressure.

For boiler pressures below 200 lb. use PN-9137-C, .257 inch diam., For 200 to 275 use PN-9137-D, .236 inch diam., For 275 and above use PN-9137-B, .214 inch diam.

When ordering, give part numbers. Do not use reference numbers.

FIG. 3. Turbine for Cold Water Pump.
Size 64 - SAS
Two No. 9137-J Nozzles (Each .214" Diam.)
All parts to be ordered from PYLE NATIONAL unless otherwise specified.



Part No.	Name of Part	Part No.	Name of Part	Part No.	Name of Part
FW-11	Exhaust Screen	FW-9102-A	Turbine Cover (Continued)	FW-9125	Turbine Ball Bearing
FW-19-B	Pipe Plug	1-19-B	Pipe Plug	FW-9128	Ball Bearing Nut
FW-19-F	Pipe Plug	1-19-F	Pipe Plug	FW-9135-FA	Nozzle Block
FW-19-J	Pipe Plug	1-19-J	Pipe Plug	FW-9135-X	Nozzle Block and Nozzles Assembly
FW-19-R	Pipe Plug	4-647	Hexagon Head Cap Screw	2-19-F	Pipe Plug
FW-47	Hexagon Head Cap Screw	4-647-B	Lock Washer	2-1948-F	Dowel Pin
FW-122-2A	Round Head Screw	1-9102-B	Turbine Cover and Bushing	1-9135-FA	Nozzle Block
FW-209	Oil Cup Cover Chain Screw	1-9116-B	Lock Nut	2-9137-J	Nozzle
FW-213-9B	Flat Head Screw	1-9118	Valve and Stem	2-9138-A	Retaining Nut
FW-647	Hexagon Head Cap Screw	1-9170-B	Spring	2-9138-B	Aligning Pin
FW-647-1MR	Lock Washer	1-9170-B	Spring	Nozzle	
FW-647-2	Hexagon Head Cap Screw	Turbine Cover Complete		FW-9137-J	Guide Passage Assembly
FW-647-3	Hexagon Head Cap Screw	2-647-1MR	Cap Screw	FW-9139-A	Retaining Nut
FW-647-4	Hexagon Head Cap Screw	3-647-F	Cap Screw	FW-9139-B	Aligning Pin
FW-1819-A	Oil Cup Cover Chain	1-9102-A	Turbine Cover	FW-9148-A	Brake Shoe
FW-1868-A	Packing Ring	1-9135-K	Nozzle Block Assembly	FW-9182	Ball Bearing Retaining Plate
FW-1847-E	Lock Washer	1-9137-KCP	Guide Passage Assembly	FW-9189	Valve and Stem Assembly
FW-1946-E	Dowel Pin	Ball Bearing Housing Cap		FW-9170-B	Spring
FW-2024-K	Shaft Key	Ball Bearing Housing Gasket		FW-9178	Pump Ball Bearing Cap
FW-3519-A	Oil Cup Cover	Turbine Wheel Assembly		FW-9179-G	Ball Bearing Cover Gasket
FW-3519-B	Oil Cup Body	1-9112-ACP	Turbine Wheel Assembly	FW-9179	Stuffing Box Cover Assembly
FW-3519-CP	Oil Cup Assembly	1-9112-ACP	Turbine Wheel Assembly	#1-9179-A	Stuffing Box Cover
1-209	Oil Cup Cover Chain Screw	1-9146-A	Brake Shoe	1-9179-B	Stuffing Box Cover Stud
1-1819-A	Oil Cup Cover Chain	Packing Ring and Retainer Assembly		1-LTB-4-A	Wing Nut
1-3519-A	Oil Cup Cover	3-1688-A	Packing Ring	FW-9179-B	Stuffing Box Cover Stud
1-3519-B	Oil Cup Body	#1-9115	Retainer	FW-9180-C	Hinge Pin
Eyebolt		Outer Packing Sleeve		FW-9185	Pump Ball Bearing
FW-4006	Turbine Casting	Ballows and Plates Assembly		FW-9186	Oil Agitator
FW-9101	Turbine Packing Housing Gasket	Lock Nut		FW-10048-S	Hexagon Head Cap Screw
FW-9101-G	Turbine Packing Housing	Wheel Retaining Nut		FW-COT-11	Cotter Pin
FW-9101-P	Turbine Cover	Shaft Assembly		FW-LTB-4-A	Wing Nut
FW-9102-A	1-19-B Pipe Plug	2-3024-K	#8 Woodruff Key		
		#1-9124-A	Shaft		

*Not shown in cut

28601 Steam Strainer at entrance to turbine 1" SARCO fitted with screen #29797 having 3/32" holes - (This to be ordered from Worthington.)

PART NUMBERS		NAME OF PART
Ref. No.		
1	29192	Heater shell
2	29193	Heater cover
3	29854	Exhaust check valve seat
4	29852	Exhaust check valve
5	29194	Stud for check valve guard
6	29137	Spacer for check valve guard stud
6A	29717	Nut for guard stud
7	29716	Wire for check valve guard stud
8	34894	Control valve bushing - 6 1/2" SA only
9	29633	Control valve bushing with increased port area - for 6 1/2" SAS only
10	29634	Control valve
11	29632	Control valve cover
12	29195	Control valve rod with bushing #29330
13	7A	Lock washer
14	223	Nut for valve rod
15	29636	Valve rod link with bushing #29330
16	29639	Valve rod pin
17	2316	Cotter pin
18	29411	Float with shank
19	29767	Rivets for float spring
20	29868	Float spring
21	129408	Spray valve sleeve
22	29689	Float lever
23	29687	Pushing for float lever
24	29601	Float lever pin
25	29638	Nut for float lever pin
26	29639	Cotter pin for float lever pin
27	29196	Spray chamber with 1/2" conduit pipe and fittings
28	29804	Spray valve
29	29826	Spray valve seat
30	29117	Spray valve spring
31	29233	Spray valve guard
32	29639	Split pin for spray valve
33	29194	Eye bolt
34	29642	Cold water inlet flange (two bolt)
35	29694	Ball joint ring for cold water inlet flange (two bolt)
36		Bolts for cold water inlet flange
37		Bolts for pump exhaust flange
38A	29450	Nuts
39B	29329	Pump exhaust and air vent flange
40	29007	Air vent flange
41	29453	Ball joint ring for pump exhaust and air vent
42	29878	bolts for air vent flange
43	29452	Control valve body with 1/2" connections - 6 1/2" SA only
47	29605	Control valve body with 1" connections - for 6 1/2" SAS only
48	29807	Air vent plug
49	29608	Air vent pipe
5	29197	Gasket for heater cover
E	29618	Gasket for spray valve seat
E2	29600	Gasket for control valve cover
E3	29606	Gasket for control valve body
50	29638	Cold water connection (two bolt)
51	29637	Spray valve plate
E1	29639	Gasket for spray valve plate
E3	29640	Gasket for cold water connection
13	1 478	Lock washer for spray valve seat stud nut
	129779	1/2" steam strainer at heater cover with screen 29781 with 1/32" holes for 6 1/2" SA only
	129781	1" steam strainer at heater cover with screen 29788 with 1/32" holes for 6 1/2" SAS only

† Not shown in cut. When ordering, give part numbers. Do not use reference numbers.





Fig. 4. Heater




FIG. 5. Hot Water Pump

Ref. No.	Part No.	NAME OF PART
1	23361	Steam cylinder
2	23362	Steam piston
3	23363	Steam piston ring
4	23364	Steam cylinder head
5	23365	Reversing valve complete
6	23366	Reversing valve, large end
7	23367	Valve steam ring, large end
7A	23368	Valve compression ring, large end
8	23369	Reversing valve, center
9	23370	Valve exhaust ring
10	23371	Reversing valve, small end
11	23372	Valve steam ring, small end
11A	23373	Valve compression ring, small end
12	23374	Reversing valve bolt
13	23375	Nut for valve bolt
14	23376	Cotter pin for valve bolt
15	23377	Valve chest bushing
16	23378	Valve chest cover
17	23379	Pump cylinder - SA
18	23380	Pump cylinder head
19	23381	Pump cylinder lining
20	23382	Clean-out cover
21	23383	Pump piston
22	23384	Pump piston packing ring
23	23385	Drain valve
24	23386	Stuffing box
25	23387	Stuffing box gland
26	23388	Stuffing box cap
27	23389	Piston rod packing (See-RO)
28	23390	Piston rod packing (chevron)
29	23391	Suction valve
30	23392	Discharge valve
31	23393	Suction valve seat
32	23394	Discharge valve seat
33	23395	Suction valve spring
34	23396	Discharge valve spring
35	23397	Pump valve cap
36	23398	Piston rod
37	23399	Piston rod nut, steam end
38	23400	Piston rod nut, pump end
39	23401	Cotter pin, steam end
40	23402	Cotter pin, pump end
41	23403	Eye bolt
42	23404	Drain cock
43	23405	Pipe nipple for drain valve
44	23406	Locking pawl pin
45	23407	Cotter pin, for locking pawl pin
46	23408	Reducing bushing
47	23409	Nut for inside steam head
48	23410	Complete set steam valve gear rings
49	23411	Locking pawl
50	23412	Gasket for steam chest cover
51	23413	Gasket for steam cylinder head - copper
52	23414	Gasket for pump cylinder head
53	23415	Gasket for pump valve cap
54	23416	Gasket for clean-out cover
55	23417	Pump cylinder with feet on bottom of cylinder for SA
56	23418	Parts supplied only when specified.
57	23419	Not shown in cut.
58	23420	When ordering, give part numbers.
59	23421	Do not use reference numbers.




FIG. 6. Drifting Control Valve (Cushion Type)

Ref. No.	No. Req.	Part No.	Size Unit	NAME OF PART
1	1	29385	6 1/2 BA	Valve body (1/2" control connection)
1	1	29795	"	Valve body (1" control connection)
2	1	28932	"	Bushing
3	2	28928	"	Piston cover
4	1	28787	"	Piston
5	2	28935	"	Piston ring
6	1	29788	"	Piston rod
7	2	36176	"	Slotted nut
8	1	28604	"	Valve
9	1	29789	"	Spring
10	1	29785	"	Cushion sleeve
11	1	29786	"	Cushion ring
12	1	29783	"	Cushion chamber
13	1	29784	"	Cushion piston
14	2	222	"	Cotter pin
15	3	28937	"	Gasket

It is preferable that the brake shoe be placed so that the direction of rotation is as shown in view B. The brake shoe will also give good service if it should be placed as shown in view "A".

If the housing is not excessively scored and the diameter has not increased more than $1/32$ inch the brake shoe only should be renewed.




FIG. 7. Locomotive Feedwater Heater Brake Shoe Tolerances.




FIG. 8 Guide Ring for Cold Water Pump




FIG. 9 Exhaust Check Valve Service








FIG.10 Control Valve Assembly for Heater

Ref. No.	NAME OF PART
1	Primary steam port in bushing
2	Secondary steam port in bushing
3	Reversing port in bushing
4	Starting port in bushing
5	By pass slot in bushing
6	Exhaust port in bushing
7	Exhaust outlet in bushing
8	Reversing port in valve
9	Reversing valve exhaust rings
10	Reversing valve compression rings
11	Reversing valve steam rings
12	Exhaust passage in reversing valve
13	Passage in steam chest
14	Steam port & passage in steam cylinder
15	Starting port in steam cylinder
16	Cushion port in steam cylinder
17	Reversing port in steam cylinder
18	Exhaust outlet in steam cylinder
19	Steam piston rings



Ref. Letter	New	Wear Limit
A	.008 to .013	3/64
B		.024
C	.007 to .010	
D	.002 to .004	.010
	.002 to .004	.008
	.005 to .010 for 1 7/16, 1 11/16 and 2" dia steel rings	3/32
	Gap in piston rings	.020 to .030 5/32
	Drive fit on steam chest bushing	.003 to .005

FIG. 11. Dimensions and Tolerances for Steam Cylinder.



A	a	B	b	C	D	E	F	G	H	I	L	M	m	N	O
7/16	17/32	5/32	1/4	3 5/32	3/8	2 25/32	29/32	3 5/8	4 1/8	7 3/4	5/32 to 3/16	1/32 to 3/64	1/8	7/8	7/8

FIG. 12. Dimensions and Tolerances
for Pump Valve Service

VALVE SPRINGS										Strength at Initial Length, Pounds	
Where Used	Part No.	Size B.M.G.	Wire Diameter, Inches	Total Number of Coils	Ins. Diameter Top, Inches	Out Diameter Bottom, Inches	Uncompressed Length, Inches	Initial Compressed Length, Inches		When New	Limit Due to Service
Suction	28786	11	.12	13	1 3/16	2 5/16	3 7/8	2 11/16		5 1/2	4
Discharge	28787	7	.18	11	1 5/16		3 1/2	2 1/2		40	28
Drift. control valve	29789	11	.120	9	1 3/8		3 7/16	1 7/8		20	14
Spray Valve	29117	9	.148	8	1 13/16		3 1/2	2 5/16		18	13

Rod Dia. A	Box Dia. B	Depth of Box C	D	E	Sea-Ro Packing		Total Pack- ing Depth	No. of Chevron Rings Per Box	*Chevron Packing		Boxes Per Pump	
					No. of Rings Per Box	Part Number			Standard to 1/16" Undersize	Part No. 1/16" to 1/8" Undersize		
2 1/4"	3	2 3/8"	3/16"	13/16"	6	28583	1 7/8"	6	29443	29444	4	2

*In Addition To
Adapter Rings




FIG. 13. Dimensions for Piston Rod Stuffing Box and Packing.

Dia. "A"	Dia. "B"	Groove Width "C"	Packing Width "D"	Standard Including $\frac{3}{32}$ Oversize				Between $\frac{3}{32}$ And $\frac{3}{16}$ Oversize				Between $\frac{3}{16}$ And $\frac{9}{32}$ Oversize			
				"E"	"F"	"G"	Part No.	"E"	"F"	"G"	Part No.	"E"	"F"	"G"	Part No.
8 1/2"	6 15/16"	5/8"	5/8 LESS .017 .020	8 7/8"	7 1/2"	13/16"	29379	9"	7 1/2"	7/8"	29445	9 3/32"	7 1/2"	59/64"	29454




FIG. 14. Dimensions of Piston Groove and Packings, Solid Type Hot Water Pump Pistons.

THE PENNSYLVANIA RAILROAD

LOCOMOTIVE MAINTENANCE INSTRUCTIONS NO. L-58

INSTRUCTIONS FOR OPERATING AND MAINTAINING WORTHINGTON LOCOMOTIVE
BOILER FEED PUMP AND FEED WATER HEATER, TYPES SA AND SAS, SIZE 6 $\frac{1}{2}$

Supplement No. 1

Issued Philadelphia, Pa.
May 23, 1947

The following shall be added to the second paragraph under
"OPERATION" on Page 3 of the present issue of the Circular:

On the road when the tender is nearly empty or in using the
track trough, the suction pipe may become full of air, and in
winter, full of steam, from excessive use of the anti-freeze valve.
The cold pump will then be air or steam bound and will not deliver
water. The pump should then be stopped and the air vent valve
(Part 38, Fig. 1) in the cab, opened and, if necessary, the pet
cocks on the top of the cold pump suction line opened.

H. T. COVER
Chief of Motive Power.

Supplement No. 1
L-58