

PROFILE

MT-1- 5/8" MESSENGER - 336,400 C.M. CONTACT

MT-2- 5/8" MESSENGER - 4/0 CONTACT

PLAN

MAIN TRACK 2-WIRE SYSTEM

BILL OF MATERIAL

AIR BREAK	DESCRIPTION OF CONTACT WIRE	DET A	DET AS	DET B	DET C	DET D	DET DS	HANGER XHA8	HANGER R	SPREADER XHA8
MT-1a	STR GR / STR GR	2	—	2	—	—	—	2	—	2
MT-1b	GR GR / GR GR	2	—	—	2	—	—	2	—	2
MT-1c	STR GR / GR GR	2	—	1	1	—	—	2	—	2
MT-2a	STR GR / GR STR	1	2	—	—	—	2	—	2	2
MT-2b	GR GR / GR GR	2	—	—	—	2	—	2	—	2
MT-2c	STR GR / GR GR	1	1	—	—	1	1	1	1	2

STR = STRANDED WIRE GR = GROOVED WIRE



PROFILE

MT-3- 5/8" MESSENGER - 336,400 C.M. CONTACT - 4/0 AUXILIARY

MT-4- 5/8" MESSENGER - 4/0 CONTACT - 4/0 AUXILIARY

PLAN

MAIN TRACK 3-WIRE SYSTEM

BILL OF MATERIAL

AIR BREAK	DESCRIPTION OF CONTACT WIRE	DET A	DET E	DET F	DET G	DET H	HANGER XHA8	SPREADER XHA8
MT-3a	STR GR / GR STR	2	2	—	—	—	2	2
MT-3b	GR GR / GR GR	2	—	2	—	—	2	2
MT-3c	STR GR / GR GR	2	1	1	—	—	2	2
MT-4a	STR GR / GR STR	2	—	—	2	—	2	2
MT-4b	GR GR / GR GR	2	—	—	—	2	2	2
MT-4c	STR GR / GR GR	2	—	—	1	1	2	2

STR = STRANDED WIRE GR = GROOVED WIRE



PROFILE

X-OVER AIR BREAK - 5/8" MESSENGER & 4/0 CONTACT

5/8" MESSENGER & 336,400 CM CONTACT



PLAN

NOTE
OMIT SP-3 WHEN INSULATOR IS 20' OR LESS FROM SUPPORT

BILL OF MATERIAL

AIR BREAK	DESCRIPTION OF CONTACT WIRE	Z	X	Y	DET A	DET AS	DET B	DET C	DET D	DET DS	HANGER XHA8	HANGER R	HANGER XHA16	HANGER JD OR J	HANGER JC OR XHA16L	SP-2	SP-3	SP-XHA8
X065A	5/8 COMP / 4/0 / 4/0 / 5/8 COMP	65'	10'	5 SPACES @ 9'	2	—	2	—	—	—	2	—	2	6 SEE NOTE ①	—	2	2	2
X060A	" " " "	60'	10'	5 SPACES @ 8'	2	—	2	—	—	—	2	—	2	6 "	—	2	2	2
X050A	" " " "	50'	10'	5 SPACES @ 6'	2	—	2	—	—	—	2	—	2	6 "	—	2	2	2
X065B	2-336,400 / 336,400 / 2-336,400	65'	10'	5 SPACES @ 9'	2	—	—	2	—	—	2	—	2	6 SEE NOTE ①	—	2	2	—
X060B	" " " "	60'	10'	5 SPACES @ 8'	2	—	—	2	—	—	2	—	2	6 "	—	2	2	—
X050B	" " " "	50'	10'	5 SPACES @ 6'	2	—	—	2	—	—	2	—	2	6 "	—	2	2	—
X065C	5/8 COMP / 4/0 / 4/0 / 2-336,400	65'	10'	5 SPACES @ 9'	2	—	1	1	—	—	2	—	2	6 SEE NOTE ①	—	2	2	2
X060C	" " " "	60'	10'	5 SPACES @ 8'	2	—	1	1	—	—	2	—	2	6 "	—	2	2	2
X050C	" " " "	50'	10'	5 SPACES @ 6'	2	—	1	1	—	—	2	—	2	6 "	—	2	2	2
X060D	5/8 COMP / 4/0 / 4/0 / 5/8 COMP	60'	7.5'	5 SPACES @ 9'	—	2	—	—	2	—	2	—	2	6 SEE NOTE ①	—	2	2	2
X050D	" " " "	50'	7.5'	5 SPACES @ 7'	—	2	—	—	2	—	2	—	2	6 "	—	2	2	2
X040D	" " " "	40'	7.5'	5 SPACES @ 5'	—	2	—	—	2	—	2	—	2	—	6 SEE NOTE ②	2	2	2
X030D	" " " "	30'	5'	5 SPACES @ 4'	—	2	—	—	2	—	2	—	2	—	6 "	2	2	2
X060E	5/8 COMP / 4/0 / 3/0 / 4/0	60'	7.5'	5 SPACES @ 9'	2	—	—	—	2	—	2	—	2	6 SEE NOTE ①	—	2	2	2
X050E	" " " "	50'	7.5'	5 SPACES @ 7'	2	—	—	—	2	—	2	—	2	6 "	—	2	2	2
X040E	" " " "	40'	7.5'	5 SPACES @ 5'	2	—	—	—	2	—	2	—	2	—	6 SEE NOTE ②	2	2	2
X030E	" " " "	30'	5'	5 SPACES @ 4'	2	—	—	—	2	—	2	—	2	—	6 "	2	2	2
X060F	5/8 COMP / 4/0 / 4/0 / 4/0	60'	7.5'	5 SPACES @ 9'	1	1	—	—	1	1	2	—	2	6 SEE NOTE ①	—	2	2	2
X050F	" " " "	50'	7.5'	5 SPACES @ 7'	1	1	—	—	1	1	2	—	2	6 "	—	2	2	2
X040F	" " " "	40'	7.5'	5 SPACES @ 5'	1	1	—	—	1	1	2	—	2	—	6 SEE NOTE ②	2	2	2
X030F	" " " "	30'	5'	5 SPACES @ 4'	1	1	—	—	1	1	2	—	2	—	6 "	2	2	2

NOTE ① - USE "JD" IN HIGH SPEED AREA. USE "J" IN SLOW SPEED AREA.

NOTE ② - USE "XHA16L" WHEN CALLED FOR ON CATENARY PROFILE.

NOTE 3 - WHENEVER INSULATORS SLOPE UPWARD FROM "R" OR XHA8 HANGER OR NOTE "REVERSE INSULATORS" APPEARS ON CATENARY PROFILE, SUBSTITUTE ASSEMB. "AR" FOR "A" AND "ASR" FOR "AS"



HANGER "R"



HANGER XHA16
HANGER XHA16L



SPREADER SP-3



IF SPREADER IS USED WITH "JC" OR "J" HANGERS PUT CONTACT WIRE DIRECTLY INTO CLIPS.

SPREADER SP-2



DETAIL "JD"



HANGER XHA8
SPREADER XHA8



DET. "DS" - 5/8" COMP. STRAND & 4/0 CONTACT



DET. "A" - 5/8" MESSENGER & 5/8" MESSENGER INSULATORS IN NORMAL POSITION



DET. "AR" - 5/8" MESSENGER & 5/8" MESSENGER INSULATORS IN REVERSED POSITION



DET. "AS" - 5/8" MESSENGER & 5/8" MESSENGER - SPECIAL INSULATORS IN NORMAL POSITION



DET. "C" - 336,400 C.M. CONTACT & 336,400 C.M. CONTACT
DET. "D" - 4/0 CONTACT & 4/0 CONTACT
DET. "F" - 4/0 AUX. - 336,400 C.M. CONTACT & 4/0 AUX. - 336,400 C.M. CONTACT
DET. "H" - 4/0 AUX. - 4/0 CONTACT & 4/0 AUX. - 4/0 CONTACT

DET. "ASR" - 5/8" MESSENGER & 5/8" MESSENGER - SPECIAL INSULATORS IN REVERSED POSITION



DET. "DSA" - 5/8" COMP. STRAND & 4/0 CONTACT



DET. "B" - 5/8" COMP. STRAND & 336,400 C.M. CONTACT
DET. "E" - 5/8" COMP. STRAND & 4/0 AUX. - 336,400 C.M. CONTACT
DET. "G" - 5/8" COMP. STRAND & 4/0 AUX. - 4/0 CONTACT

ALTERNATE ASSEMBLIES - TO BE USED WHEN O.B. FITTINGS ARE NOT AVAILABLE.



DET. "BA" - 5/8" COMP. STRAND & 336,400 C.M. CONTACT
DET. "EA" - 5/8" COMP. STRAND & 4/0 AUX. - 336,400 C.M. CONTACT
DET. "GA" - 5/8" COMP. STRAND & 4/0 AUX. - 4/0 CONTACT

ALTERNATE ASSEMBLIES - TO BE USED WHEN O.B. FITTINGS ARE NOT AVAILABLE



DET. "CA" - 336,400 C.M. CONTACT & 336,400 C.M. CONTACT
DET. "DA" - 4/0 CONTACT & 4/0 CONTACT
DET. "FA" - 4/0 AUX. - 336,400 C.M. CONTACT & 4/0 AUX. - 336,400 C.M. CONTACT
DET. "HA" - 4/0 AUX. - 4/0 CONTACT & 4/0 AUX. - 4/0 CONTACT

ALTERNATE ASSEMBLIES - TO BE USED WHEN O.B. FITTINGS ARE NOT AVAILABLE.

BILL OF MATERIAL - HANGER & SPREADER ASSEMBLIES

PIECE MARK	DWG NO	"R" HANGER	XHA8 HANGER	SP-2 SPREADER	SP-3 SPREADER	JD HANGER	XHA8 HANGER
BC-24C	ET-1086-E	—	—	—	4	—	—
BC-25	ET-1088-E	—	—	2	—	—	—
BC-31	ET-1080-E	—	—	1	—	—	—
BC-35	ET-1081-E	—	—	—	2	—	—
BC-37	ET-1083-E	—	—	1	2	—	—
TS-38	ET-258-E	—	2	—	—	—	—
BB-3	ET-146-E	—	—	1	2	—	—
BB-34	ET-148-E	—	—	1	2	2	—
BB-5	ET-146-E	—	—	—	—	—	—
BB-22	ET-148-E	—	—	1	2	2	—
1.125 CU. TUBE	THIS DWG	♣	♣	—	—	—	#
1/4" CU FILLER	THIS DWG	2	2	—	—	—	2
34" HANGER ROD HOOK & THREAD TYPE	ET-1086E	—	—	△	△	—	—
DB	4E-100	—	—	—	2	—	—
UB-27	ET-146E	—	1	—	—	4	2
36" HANGER ROD HOOK TYPE	ET-1086-E	—	—	—	—	*	—
HC-29A	ET-1028-E	—	—	—	—	4	—
BC-26B	ET-1078-E	—	—	—	—	2	—
42" DUMMY 6-0 LG.	—	—	—	—	—	1	—
1.625 CU. TUBE	THIS DWG.	—	♣	—	—	—	—
MW5	ET-170-E	—	1	—	—	—	2
BC-24B	ET-1087-E	—	—	—	—	2	—

♣ CUT IN FIELD.

BILL OF MATERIAL — PREFERRED ASSEMBLIES

ITEM	DESCRIPTION	DET "A" OR "AR"	DET AS	DET B	DET C	DET D	DET DS	DET E	DET F	DET G	DET H	DET ASR
1	EYE END SOCKET	MF3	MF3	MF3	OB 336,400	OB 4/0	MF3	MF3	OB 5/8 & 4/0 / 336,400	MF3	OB 5/8 & 4/0 / 4/0	2-MF3
2	CLEVIS END SOCKET	MF1	MF1	OB 336,400	OB 336,400	OB 4/0	OB 4/0	OB 336,400	OB 5/8 & 4/0 / 336,400	OB 5/8 & 4/0 / 336,400	OB 5/8 & 4/0 / 4/0	—
3	INSULATOR	5-A2	3-A2	3-A2	3-A2	3-A1	3-A1	3-A2	3-A2	3-A2	3-A2	3-A2
4	PIN	NP5	NP5	—	—	—	ND2	—	—	—	—	NP5
5	BOLT	—	BG5	—	—	—	B65	—	—	—	—	B65
6	ADAPTER	—	ND2	—	—	—	ND2	—	—	—	—	ND4

BILL OF MATERIAL — ALTERNATE ASSEMBLIES

ITEM	DESCRIPTION		DET "BA"	DET "CA"	DET "DA"	DET "DSA"	DET "EA"	DET "FA"	DET "GA"	DET "HA"
1	EYE END SOCKET		MF3	—	—	MF3	MF3	—	MF3	—
3	INSULATOR		3-A2	3-A2	3-A1	3-A1	3-A2	3-A2	3-A2	3-A2
4	PIN		NP5	NP5	NP2	NP2	NP5	NP5	NP5	NP5
5	BOLT		—	—	—	BG5	—	—	—	—
6	ADAPTER		—	—	—	ND2	—	—	—	—
7	EYE END THIMBLE SHACKLE		—	57A	59	—	—	512	—	512
8	CLEVIS END THIMBLE SHACKLE		58	58	510	510	511	511	511	511
9	WIRE CLIPS		3-5/8	6-5/8	6-1/2"	3-1/2"	3 1/2" & 5/8"	6-5/8"	6 1/2"	12-1/2

REFERENCE DRAWINGS

SOCKETS
MF1 - ET-662-E
MF3 - ET-662-E

INSULATORS
INSULATOR A1 - 11B-1201
INSULATOR A2 - 11B-1201

PINS & BOLTS
ND2 - 11B-1206
ND5 - 11B-1206
B65 - ET-145-E

THIMBLE SHACKLES
57A - 14E-86
58 - 14E-85
59 - 14E-87
510 - 14E-88
511 - ET-44-E
512 - ET-45-E

O.B. CLAMP - EYE END

WIRE SIZE	CAT NO.	O.B. DWG NO.
336,400	-	34957
4/0	20723 -	21782
4/0 (3/0)	-	22309
4/0	-	22312
4/0	-	

O.B. CLAMP - CLEVIS END

WIRE SIZE	CAT NO.	O.B. DWG NO.
336,400	-	34935
4/0	20720	14000
4/0	-	22308
336,400	-	
4/0	-	22313
4/0	-	

MISCELLANEOUS
ND2 - ET 449-E
1/2" WIRE CLIP - ET 556-E
5/8" WIRE CLIP - ET 556-E
ND4 - ET 394-F

NOTE 4
OB WITH [illegible] HEADS

THIS DRAWING SUPERSEDES
DRAWINGS ET-800-C & ET-890-C
AND PART OF DWG. 11B-1292

ISSUE No.	DATE	DWN	CH'D	REMARKS	APPR
4	3-27-57	RAL	RDT	REV. BILL OF MATERIALS	
3	4-15-56	JRS	RDT	GENERAL REVISION	
2	9-14-49				
1	8-8-47			ORIGINAL	

CORRECT SCALE

GIBBS HILL INC. CONSULTING ENGINEERS NEW YORK

ET-1102-C-4

THE PENNSYLVANIA RAILROAD
ELECTRIFIED TERRITORY

DOUBLE MESSENGER AIR BREAK DETAILS

PHILADELPHIA
W. F. Lower
CHIEF OF MOTIVE POWER

C

J. Stair, Jr.
ELECTRICAL ENGINEER

downloaded from http://PRR.Railfan.net
Original drawing from the collection of Rob Schoenberg
scan ©2010 Rob Schoenberg, Commercial reproduction or distribution prohibited